



## Professional Cubicle Curtains

1-800-258-8817 • custsvc@ModoMed.com

www.Modomed.com

### **CUBICLE CURTAIN CARE AND SPECIFICATIONS**

#### **FABRIC: Parse**

##### **FEATURES:**

- Greenguard Gold Certified
- LBC Red List Free
- PFAS Free
- REACH Compliant
- Reversible

##### **SPECIFICATIONS:**

- Fabric Content: 100% FR Polyester
- Backing: None
- Width: 72"
- Repeat: 22¼" V
- Railroad Repeat: 22¼" H
- Bolt Size: 65 yards
- Weight: 12.6 oz/ly

##### **Flammability Tests Passed:**

- ASTM E 84 Unadhered
- BS 5867
- CAN ULC S109
- GB/T 17591
- NFPA 701

##### **Durability Tests Passed:**

- Lightfastness: AATCC 16E, 60+ hours



##### **CARE INSTRUCTIONS:**

- Using mild soap or detergent, machine wash on synthetic setting with a high water level and mild agitation. Temperature should not exceed 160F. Extract gently. Wash with like materials.
- If necessary, machine wash with a diluted bleach solution. This textile may also be spot cleaned with a diluted bleach solution as long as the bleach solution is rinsed thoroughly after application. If bleach is used without adequate rinsing, degradation to the textile will occur.
- Air, cabinet, or tumble dry at a low temperature. Do not exceed 3-5 minutes on a synthetic cycle at a maximum of 140F. Hang or fold immediately after drying.
- Hand Iron - Iron at low heat setting (275F) with a damp press cloth or steam iron with a dry press cloth.
- Grid Head Press - Press for short intervals with minimum steam. Do not lock head.
- Flat Bed Press - Press dampened drapery using cloth covering.
- Avoid prolonged contact with heat.

\*ModoMed relies solely upon the flame retardant tests from the mills and makes no claims, directly or implied, regarding flame retardant properties of any fabrics.